

RM12_S2P



User Manual

Ver 1.0 - Date: 02/2006

<http://www.datoptic.com>

Copyright Notice

The proprietary information contained in this document is protected by the copyright laws. All rights are reserved. It does not allow any non-authorization in copied, photocopied, translated or reduced to any electronic or machine readable in whole or in part form without prior written consent from the manufacturer except for copied by the purchaser for backup purposes. The manufacturer keeps the rights in the subject to change the contents of this manual without prior notices in order to improve the function design, performance, quality and reliability. The author assumes no responsibility for any errors or omissions, which may appear in this manual. Nor does it make a commitment to update the information contained herein.

Trademarks

All other product names or trademarks mentioned in this manual are the properties of their respective owners.

Disclaimer

The manufacturer makes no representations or warranties, expressed, statutory or implied, regarding the fitness or merchantability of this product for any particular purpose. Further, the manufacturer is not liable for any damages, including but not limited to, lost profits, lost savings, or other incidental or consequential damages arising out of the use of this product.

The manufacturer also reserves the right to make any improvements or modifications to the product described in this manual at any time, without notice of these changes.

Table of Contents

Unpacking RM12_S2P

Chapter 1 Introduction

1.1 Overview

1.2 Key Feature

1.3 Specification

Chapter 2 Installation Introductions

Chapter 3 System Starting

3.1 Indicators and Switch

Special Notes

Unpacking RM12_S2P:

Open the DATOptic RM12_S2P box and carefully remove the RM12_S2P unit and accessories, the **RM12_S2P** and accessories including the following items:

- **RM12_S2P** unit x1
- eSATA_PCIX (optional) – PCI and PCIX compatible
- eSATA cable x3
- Power Cable x1
- Screws and screwdriver (HDD tray unlock tool) kit
- Downloadable Manual & Drivers (were needed) kit

Chapter 1 Introduction

1.1 Overview

The **DATOptic.com RM12_S2P** is an easy-use and cost- effective 3.5" SATA and SATA II Hot-swappable hard disk drive storage enclosure that can be used as **Near-Line RAID Storage Cluster system** mass storage device, delivering of large amounts of expandable storage space. An ideal for large storage libraries, digital video & digital audio files, backups and flexibility to grow with your storage needs.

RM12_S2P is ideal for data centre, departmental and DVR server users who need a flexible, universal storage enclosure that utilizes a common storage building block for their current and future data needs. **RM12_S2P** near-line storage systems intended for use with servers delivering large business data storage and applications with which require excellent accessibility, serviceability, and large storage capacity.

Front View



Rear View

Model: RM12S_P with 3x eSATA connection



1.2 Key Feature

- eSATA interface x3;
- 4U rack height;
- Supports up to twelve (12x) 3.5" SATA disk drives;
- Supports 48Bit LBA – drives larger than 130GB (up-to 500GB)
- Excellent cooling system ensures the drives' reliability;
- Hot-swappable disk drive tray with special designed power-off and lock mechanism;
- Monitor and alarm notification for temperature and fans

1.3 Specification

Model DATOptic.com RM12_S2P

Construction Heavy duty 1.2mm steel, meets FCC/CE Class

Drive Bay 12 x hot-swappable SATA or SATA II drive

Interface eSATA

Cooling Fan Three 70mm fans

Switch Power ON/OFF x 1

Indicator HDD Power x 12, HDD Data Access x 12,

Temperature monitor, fan monitor

Maximum Storage Capacity 6000GB/ 6 terabytes

Data speed 3.0Gbps

RAID Support RAID0, RAID1, RAID 5 and JBOD (depend on RAID controller card)

Any operating system that supports SATA II with port multiplier

Dimensions (W x D x H) 19" x 18.5" x 6.89" (483mm x 470mm x 175mm)

Temperature Range Operating 41°F to 104°F (5°C to 40°C)

Shipping -31°F to 167°F (-35°C to 75°C)

Weight 35 lb / 16 kg (without hard drive)

Chapter 2 Installation Introductions

Insert the small screwdriver into the unlock hole of the drive carrier, pull the key to the side to release the handle, and then withdraw the drive carrier.



Chapter 3 System Starting

3.1 Indicators and Switch

3.1.1 LED Indicators Power LED (Green): Always on

Data Access LED (Yellow): Flashing when data's writing or reading

3.1.2 Alarm Indicators

Temperature Monitoring:

This indicator stays green when the operating temperature inside the chassis is normal (under 105°F). It will turn red when it is over the normal operating temperature.

Fan Monitoring:

When the fans operate normally, this indicator stays green. It will turn red when one of the fans malfunction or stop working.

POWER LED Data Access LED

3.1.3 Switch

3.1.3.1 SW: Alarm Reset

The alarm will go off when the operating temperature is above limit or one of the fans stop running. You may select to stop the alarm by pressing the reset switch and have the system running continually (NOT RECOMMENDED).

3.1.3.2 RAID0 Function

Please refer to HBA document to set up RAID functions

Special Notes:

1. DO NOT force to remove drive carrier, it will cause damage if removing the drive carrier from the chassis before unlocking the carrier by using the proper key
2. Although **RM12_S2P** supports hot swappable, never withdraw a HDD that is being read or written. Before you want to disconnect /unplug SATA Device cable or withdraw a HDD, please make sure data transmission has been completed.
3. For the best result of ventilation inside the chassis, please don't open the case while **RM12_S2P** is operating.